



Instructions for Easy Installation & Assembly



elfa® Frames and Drawers

(Figure A)

Tool needed: plastic mallet

TIP

- If you don't have a plastic mallet, you can use a hammer with a wood block to protect the Frame.

Step 1

- Position the elfa® Panel runners facing inward.
- Using a plastic mallet, tap the Bottom T-Crossbars into the bottom of each Side Panel.

Step 2

- If using Back Stop Pins, put a Back Stop Pin in the back holes of the top runners before inserting the Top L-Crossbars. The remaining Back Stop Pins should be put in just prior to sliding in the Drawers.

If combining Frames, see **Figure B** below.

Step 3

- **If using a Melamine Top,** tap the Top L-Crossbars completely into each Side Panel. Place adhesive strips included in the packaging on the Top L-Crossbars. Align the Melamine Top with the crossbars and press firmly.
- **If using a Butcher Block Top,** tap the Top L-Crossbars completely into each Side Panel. Place the Butcher Block Top on the crossbars.

Step 4

- Insert remaining Backstop Pins.
- Slide in Drawers.
- If you have other Frame and Drawer accessories, install them now.

Combining elfa® Frames

(Figure B)

Step 1

- Assemble top Frame completely. See Steps 1-2 above.

Step 2

- Assemble bottom Frame, omitting the Top L-Crossbars.
- If using Back Stop Pins, put one in the back of the left and right top Runners of the bottom Frame.

Step 3

- Lower the top Frame onto the bottom Frame, making sure the Back Stop Pins are all on the back side. Secure by firmly tapping each corner of the top Frame until Bottom T-Crossbars are completely inserted into the bottom Frame.

Step 4

- Insert remaining Backstop Pins.
- Slide in Drawers.
- If you have other Frame and Drawer accessories, install them now.

